



<b>1</b> Intercambiador Principal	Rutas	118	138	280
<b>2</b> Intercambiador de Proximidad	19	119	139	281
<b>B</b> Estación de Guaguas	20	120	140	282
Paradas Preferentes	27	121	141	283
Red Ferroviaria	28	122	142	287
Tren del Norte	37	123	143	288
Tren del Sur	38	130	270	307
Red Tranviaria	75	131	271	322
Tranvía Ligero Metropolitano	91	132	276	327
	92	133	277	328
	116	136	278	
	117	137	279	

